

VIAGGIO



DETOMASO

GRATULATION ZUM ERWERB DEINER DETOMASO UHR!

Ein Roadtrip durch Italien, die Hände fest am Lenkrad und den sanften Fahrtwind spüren – dieses Gefühl verkörpert deine neue Uhr.

Du bist jetzt Eigentümer eines Zeitgebers, der sich durch hohe Präzision und innovatives Design auszeichnet. Inspiriert von klassischen Sportwagenlegenden und dem Lebensgefühl Italiens stehen DETOMASO Uhren für ein bisschen Retro und ganz viel Charakter.

Damit wir gewährleisten können, dass deine neue Uhr viele Jahre problemlos funktioniert, lies bitte sorgfältig die folgende Bedienungsanleitung. So erinnert dich deine DETOMASO Uhr stets daran, deinen ganz eigenen Takt zu finden: LIVE THE MOMENTUM

MATERIALIEN

Erst das Zusammenspiel von mutigen Ideengebern, erstklassigen Uhrmachern und ambitionierten Designern haben aus der Idee hinter DETOMASO Präzisionsarbeit werden lassen. Und diese Ambitionen spiegeln sich auch in den ausgesuchten Materialien wider.

DETOMASO verwendet nur beste Komponenten für die VIAGGIO:


Automatik Markenuhrwerk von Seiko Kaliber NH35a mit Datumsanzeige

Gehäusematerial aus antiallergenem 316L Chirurgenstahl

Kratzfestes Saphirglas

5 ATM Wasserdichtigkeit nach DIN 8310

LIVE THE MOMENTUM



PFLEGEHINWEISE

Deine Uhr soll dir viel Freude bereiten und dich lange begleiten. Schütze deine Uhr vor Stößen, Magnetfeldern, starker Hitze und Chemikalien sowie vor mechanischem Abrieb. Mit einer Wasserdichtigkeit von 5 ATM hält deine Uhr Regen, Händewaschen und Baden aus. Versuche aber dennoch sie selten Wasser auszusetzen, auch dem Armband zuliebe. Beim Tragen sollte die Krone immer in eingedrückter Position sein.

Solltest du Kondenswasser unter dem Glas sehen, muss die Uhr unverzüglich in unsere Uhrmacherwerkstatt gesendet oder ins Fachgeschäft gebracht werden, damit die Feuchtigkeit keinen Schaden anrichtet.

Eine geringe Gangabweichung für Automatikuhren ist normal. Nach 5 bis 7 Jahren kann es jedoch sein, dass das Uhrwerk an Präzision verliert und zur Revision muss. Die Revision kann in unserer Uhrenwerkstatt durchgeführt werden

(Kontakt: service@detomaso-watches.com) oder aber in einem Fachgeschäft.

EINSTELLUNG DER UHRZEIT

Ziehe die Krone heraus, in die 2. Position.

Drehe die Krone im Uhrzeigersinn, um die Stunden- und Minutenzeiger zu bewegen.

Drücke anschließend die Krone wieder in die Normalposition.

EINSTELLUNG DES DATUMS

Ziehe die Krone heraus, in die 1. Position.

Drehe die Krone entgegen dem Uhrzeigersinn. Wenn das Datum zwischen 21.00 Uhr abends und 01.00 Uhr morgens gestellt wird, dann wechselt das Datum am folgenden Tag nicht.

AUFZIEHEN DER UHR

Solltest du deine Automatikuhr einmal länger nicht tragen, kannst du sie auch per Hand aufziehen. Die Krone bleibt hierfür in Normalposition.

Für einen vollständigen Aufzug sind ca. 30 Umdrehungen notwendig. Kurz vor dem vollständigen Aufzug ist ein Widerstand zu spüren. Bitte dreh dann die Krone noch etwas länger.

Die Gangreserve der VIAGGIO beträgt 40 Stunden. So lange läuft deine Uhr, wenn sie liegt und nicht getragen wird.

CONGRATULATIONS ON YOUR NEW DETOMASO WATCH!

Hop in the car, cruise the highway, and keep life moving. DETOMASO watches embody the desire to rediscover your freedom.

You are now the owner of a watch that stands out for its high precision and innovative design. The idea is based on the Italian lifestyle and the big idols of classic automobile design in the 70s. A little retro, and a lot of character.

To ensure that we can guarantee the functionality of your watch for many years, please read the following operating instructions carefully. So your DETOMASO watch is a continuous reminder that you create your own path in life – LIVE THE MOMENTUM

MATERIALS

It started as an ambitious idea between a visionary designer and a world-class watchmaker, but has quickly transitioned to a precision timepiece. And these ambitions are reflected in the selected materials.

DETOMASO uses only the best components for the VIAGGIO:

Movement: Seiko Automatic NH35a with date

Case material: Anti-allergenic 316L surgical steel

Glass: Scratch-resistant sapphire glass


Water resistance: 5 ATM/50M/150FT

CARE INSTRUCTIONS

Your watch should accompany you for a long time. Protect your watch from shocks, magnetic fields, strong heat and chemicals, as well as mechanical abrasion. With a water resistance of 5 ATM, your watch can stand rain, washing hands and taking a bath. However, try to avoid too much water contact, also for the sake of the bracelet. The crown should always be in the depressed position when being worn.

In the event of condensation under the glass, the watch should immediately be sent to the DETOMASO watchmaker, or taken to a specialist shop in order to prevent damage from the moisture.

After 5 to 7 years, automatic watches can begin to lose their precision. After this period of time you should plan to get your watch cleaned and tuned up. We highly suggest using our watchmaker service (service@detomasowatches.com). Alternatively you can visit a local watch specialty shop at your own risk.



SETTING THE TIME

Pull out the crown to the 2nd position.

Turn the crown clockwise to move the hour and minute hands.

Then push the crown back to the pushed-in position.

SETTING THE DATE

Pull out the crown to the first position.

Turn the crown counterclockwise. If the date is set between 9pm and 1am, the date does not change on the following day.

After the date has been set, push the crown back into the pushed-in position.

SETTING THE DAY OF THE WEEK

Pull out the crown to the first position.

Turn the crown clockwise to set the date. If the date is set between 9pm and 1am, the day of the week will not change on the following day.

Push the crown back into the pushed-in position.

WINDING THE WATCH

If you should not wear your automatic watch for a longer period of time, you can also wind it up by hand. The crown remains pushed in.

Approximately 30 full rotations are needed for a complete winding. Start by turning the crown clockwise 1 turn. Repeat this until you feel a slight resistance which alerts you are nearing completion. Continue turning until you can no longer rotate the crown.

The VIAGGIO has a power reserve of 40 hours. That is how long your watch runs when it is not being worn.

DETOMASO CUSTOMER SERVICE:

DETOMASO
c/o Temporex Lifestyle GmbH
Hinsbecker Löh 10
45257 Essen / Germany
+441603976950
service@detomaso-watches.com
www.detomaso-watches.com/eu

Clients from the US please contact:

DETOMASO
c/o Zeitgeist Inc.
3600 Horizon Drive
Suite 110
King of Prussia, PA 19406 USA
service@detomasowatches.com
(215) 999-4010
www.detomasowatches.com

